

Monitor

Date: October 22, 2001

Subject: NO RASTER

Italicized information in green applies to Europe, Middle East and Africa.

DESCRIPTION

No raster may appear if contact between the A board and connector CN3009 on the A board is poor or lost. This may occur if the receptacle pins of 10-pin connector CN3009 open when the A board is removed or any time the connector lead is pulled or pressed.

As a preventive measure, perform the following modification procedure.

PARTS REQUIRED

Part No.	Description	Qty.
1-900-262-24	Micro Connector Assembly, 10P (length = 370 mm)	1
3-701-417-02	Purse Lock (11ø, Floating Type)	1

Video Products Technical Bulletin 2001-184

Worldwide Technical Bulletins for Broadcast and Professional Products

Model: PHM-20M8U, PVM-20M7MDE

Serial No: 2,000,001–2,000,275 (PHM-20M8U) 2,000,001–2,003,240 (PVM-20M7MDE)

MODIFICATION PROCEDURE

A Board (See Figure 1.)

- 1. Unlock and set aside the floating type (8ø) purse lock (A).
- 2. Remove the screw-locked purse lock (B) to release the CN3009 connector assembly.
- 3. Replace the connector assembly with the new one with longer leads.

(See Figure 2.)

4. Route leads of new assembly as shown.

NOTE: When routing the leads through the coated cable strap on the A board, allow enough slack at the CN3009 side so that pins are not subjected to stress.

ORDERING INFORMATION

NOTE: To order upgrades or for regional service center and parts ordering information, refer to the following document, which lists all contact telephone numbers:

Technical Bulletin 001999000

Canadian customers: Please order parts from your usual supplier.

DPMO01-027

Page 1 of 2

- Broadcast Professional Products Asia • Sony Australia • Sony Broadcast & Professional Europe • Sony Canada Ltd. • Sony Electronics Inc. USA • Sony Products Professional Latin America






Figure 1

