



Peripheral

Date: **June 1, 1998**

Subject: **NEW FIXTURE ASSEMBLY TOOL FOR
 BNC TERMINAL**

Model: **BKM-41HD, BKM-42HD**

Serial No: **ALL**

DESCRIPTION

The clearance between BNC digital interface terminals is too narrow to tighten or loosen the terminal nuts with a standard tool. Therefore, a fixture assembly tool has been registered exclusively for this purpose.

PARTS REQUIRED

Part No.	Description	Qty.
X-3702-037-1	Fixture Assembly	1

INSTALLATION PROCEDURE

1. Set the BNC terminal into place and finger-tighten the nut for the BNC terminal. See Figure 1.
2. Tighten the nut with the fixture assembly tool.




Figure 1