



Display

Video Products Technical Bulletin 30-2003-136

DATE: **July 7, 2003**SUBJECT: **SOFTWARE UPGRADE—VERSION 1.02**

MODEL: ***BVM-F24***
BVM-F24U

DESCRIPTION

Software version 1.02 is now available.

SERIAL NO:

BVM-F24 *2,000,001–2,000,027*
BVM-F24U 2,000,001–2,000,043

*Italicized information in green applies to
customers outside the United States.*

PARTS REQUIRED

Part No.	Description	Qty.
MBVMFOS/1	BVM-F24 Software V1.02	1

ORDERING INFORMATION

To order upgrades, contact:

Sony **SOFTWAREPLUS**® Center**Fax: 816-880-6854****Call: 800-538-7550 → Option 5****Mail:** Sony **SOFTWAREPLUS**® Center

8281 NW 107th Terrace

Kansas City, MO 64153

Customers outside the United States: *Please order parts
from your usual supplier.*

PROGRAM IMPROVEMENTS

- The upper limit for the variable range is now set for the CONTRAST control. This setting ensures that the unit complies with RF radiation requirements when the PC signal (SXGA/75 Hz, 85 Hz) is selected.

NOTE: See the supplement to the operation manual included on page 2 of this technical bulletin.

- The unit now starts properly when using the stand-by OFF/ON switch.
- With the cursor still blinking, the auto landing adjustment no longer stops before completion.

UPGRADE PROCEDURE

For detailed upgrade instructions, see Technical Bulletin 20-1998-229.

DPM002-048

変更と補足/Additions and Corrections

日本語

BVM-F24Jの取扱説明書の内容を以下のように変更・補足いたします。

26ページ

[A11] MANUALメニュー

BRIGHT、またはCONTRASTつまみを回して調整する。調整終了後、ENTER (Ent)ボタンを押すと調整値が確定される。

BRIGHT: xxxx

CONTRAST: xxxx

マニュアル調整時、画面の表示文字を消したい場合は[F1]ボタンを押します。画面から表示が消え、調整しやすくなります。文字を表示させるには、再度[F1]ボタンを押します。

デフォルト値に戻すには

対応するMANUALボタンを押すと、デフォルト値(工場出荷時の値)に戻ります。

ご注意

PC信号入力(アナログRGB)、SXGA/75HzおよびSXGA/85Hzを選択した場合、CONTRASTの数値は、表示上はMAX2000(+1000)¹⁾まで変化しますが、実際には約1500(+0500)¹⁾で制限されます。それ以上の数値に設定しても、コントラストは可変されません。

¹⁾ CONTRASTの数値は、CONT/BRT CENTERが1000に、()内の数値は0000に設定されている場合です。
CONT/BRT CENTERの設定について詳しくは、「[C4] チャンネル選択方法、電源投入時の状態(SET UP4) —SYSTEM CONFIGURATIONメニュー—」(44ページ)をご覧ください。

English

Please make the following additions and corrections on the BVM-F24E/F24U/F24A Operation Manual.

On page 22

[A11] MANUAL menu

Adjust values by turning the BRIGHT and/or CONTRAST knobs. After the adjustment, press the ENTER or Ent button to confirm the adjusted values.

BRIGHT: xxxx

CONTRAST: xxxx

When you want to erase characters from the screen while adjusting manually

Press the [F1] button. The characters disappear. To display characters, press the [F1] button again.

To reset the setting to the default

Press the corresponding MANUAL button. The adjusted value is reset to default.

Note

When the PC signals (Analog RGB), SXGA/75 Hz or SXGA/85 Hz signals are selected, the setting value of CONTRAST is displayed up to MAX2000 (+1000)¹⁾. However the actual setting value is up to around 1500 (+0500)¹⁾. Even if you set CONTRAST to more than around 1500 (+0500), the contrast is not variable.

¹⁾ The CONTRAST value shows when CONT/BRT CENTER is set to 1000 or 0000 (the value in the parentheses). For details of the CONT/BRT CENTER setting, see "[C4] Setting the Channel Selection Method and Power-Up Conditions (SET UP4) —SYSTEM CONFIGURATION Menu—" (on page 40).