



LCD Monitor
Professional Video Monitor

Video Products Technical Bulletin 30-2013-105

DATE: **September 9, 2013**

SUBJECT: **FRONT SWITCH FLASHES ALTERNATELY
BETWEEN AMBER AND GREEN**

MODEL: **LMD-941W**
PVM-741
PVM-741

DESCRIPTION

When the monitor is used in high-temperature environments, a fan error may occur. In this case, the LED on the switch of the front panel alternately flashes between amber and green.

SERIAL NO:

LMD-941W 3,000,001–3,000,438
PVM-741 ***5,000,001–5,000,070***
PVM-741 3,000,001–3,000,892

Italicized information in green applies to customers outside the United States.

PARTS REQUIRED

Part No.	Description	Qty.
1-855-245-11	DC Fan	1

ORDERING INFORMATION

To order parts online, go to: www.sony.com/servicesplus. For service or parts ordering assistance, refer to the following document, which lists all contact telephone numbers:

Technical Bulletin 00-1999-000

MODIFICATION PROCEDURE

Replace the DC fan with a new DC fan.

NOTE: Refer to the service manual for replacement details.

CONFIRMATION

Confirm that:

- The DC fan rotates correctly.
- The indicator LED does not alternately flash between amber and green.

DPMO13-012