

**Display**

---

Date: **May 29, 1995**Model: **PVM-1953MD**Serial No: **2,000,001–2,000,500**Subject: **WHITE BALANCE SPECIFICATION IN  
HIGH/LOW TEMPERATURE  
ENVIRONMENT****DESCRIPTION**

During extreme temperature changes, monitor white balance may change. To improve the white balance, perform the following modification.

**PARTS REQUIRED**

Part No.	Description	Qty.
1-247-879-11	Res, 100k $\Omega$	1

**MODIFICATION PROCEDURE****C BOARD**

1. Replace R702 with a 100k $\Omega$  resistor.
2. Perform white balance adjustment.