



Display

Video Products Technical Bulletin 30-2003-098

DATE: **March 24, 2003**SUBJECT: **DISCOLORED OR PEELING COVER CAUSED BY
POOR VENTILATION**MODEL: **PVM-5041Q**
PVM-6041QMSERIAL NO: **ALL**

*Italicized information in green applies to
customers outside the United States.*

DESCRIPTION

If the unit is housed in a rack or shelf, poor ventilation around the unit may allow the operating temperature to rise higher than room temperature.

This increase in temperature may cause excessive heat radiation, operation problems, and discoloration or peeling of the cover. When servicing the unit, check for heat-related symptoms caused by poor ventilation.

To prevent the symptoms:

- Keep the operating temperature of the unit in a range of 0 °C to 35 °C (32 °F to 95 °F).
- Ensure there is sufficient space between the unit and nearby equipment.
- Provide openings and fans around the unit for effective ventilation, if necessary.

DPM003-003