





Broadcast Products Technical Bulletin 20-2003-092

DATE: March 24, 2003 SUBJECT: REPLACING GC BOARD

MODEL: **BVM-14E1E**

BVM-14E1E/4

BVM-14E1E/4A

BVM-14E1E/A

BVM-14E1U

BVM-14E1U/3

BVM-14E5A/1

BVM-14E5E

BVM-14E5E/4

BVM-14E5E/4A BVM-14E5E/A

BVM-14E5U

BVM-14E5U/3

BVM-14E5U/9

BVM-14F1E

BVM-14F1E/1

BVM-14F1E/3 BVM-14F1E/4

BVM-14F1E/4A

BVM-14F1E/5

BVM-14F1E/5A

BVM-14F1E/A

BVM-14F1E/A1

BVM-14F1U

BVM-14F1U/1

BVM-14F1U/3

BVM-14F1U/4

BVM-14F5E

DVA 44555/

BVM-14F5E/1

BVM-14F5E/3 BVM-14F5E/4

BVM-14F5E/4A

BVM-14F5E/5

BVM-14F5E/5A

BVM-14F5E/6

BVM-14F5E/9

BVM-14F5E/A

BVM-14F5E/A1

BVM-14F5U

BVM-14F5U/1

BVM-14F5U/3

DESCRIPTION

The GC board is mounted on the G board. When replacing a GC board that has a 2-P connector, either:

- Repair the GC board by replacing individual components, or
- Replace the G board with a suffix -D or higher G board.

NOTE: The G board comes with the GC board.

For GC and G board compatibility, see Table 1.

Table 1. GC and G Board Compatibility

GC Board		G Board	
		Suffix of Mounted Circuit Board	Suffix of Printed Circuit Board
2-P connector Lead wire	→	-A	
		-В	-11
		-C	
No 2-P connector No lead wire	→	-D	-12

DPMO03-004

BVM-14F5U/4 BVM-14F5U/9 BVM-20E1E **BVM-20E1E/3 BVM-20E1E/4** BVM-20E1E/A **BVM-20E1U BVM-20E1U/1** BVM-20E1U/3 BVM-20F1E **BVM-20F1E/1 BVM-20F1E/3 BVM-20F1E/4 BVM-20F1E/5 BVM-20F1E/6 BVM-20F1E/9** BVM-20F1E/A BVM-20F1U BVM-20F1U/1 BVM-20F1U/3 BVM-20F1U/4 BVM-20F1U/9

SERIAL NO: ALL

Italicized information in green applies to customers outside the United States.

Broadcast Professional Products Asia • Sony Australia • Broadcast Professional Products Europe • Sony Canada Ltd. • Sony Electronics Inc. USA • Sony Broadcast and Professional Latin America